






Made in USA

CTL 5000 RGBW CONTROLLER SERIES



Made in USA
3 years Warranty

CTL 5000 RGBW CONTROLLER SERIES



Operation and Programing Instructions

After you have wired the modules correctly you can power your RGB Controller and adjust the brightness on every static color, press and hold the dimmer bottom until obtain the desired intensity, see color chart #1 below .

To adjust the speed sequence on mode number 9, find the RGB flash mode, a chasing effect will occur if you followed the process correctly. From here you will be able to adjust the speed by choosing 4 different speed options according to the following color chart, see color chart #2 below .

chart # 1

COLOR	SPEED
RED	FASTEST
GREEN	FAST
BLUE	SLOW
WHITE	SLOWEST

chart #2

ITEM	MODE	REMARK
1	Static Red	Brightness or color keys area available
2	Static green	Brightness or color keys area available
3	Static Blue	Brightness or color keys area available
4	Static White	Brightness or color keys area available
5	Static purple	Brightness or color keys area available
6	Static yellow	Brightness or color keys area available
7	Static Cyan	Brightness or color keys area available
8	Static Pink	Brightness or color keys area available
9	Seven color sequence	speed
10	Off	